

Sulfide

(Hydrogen Sulfide) Methylene Blue Visual Colorimetric Method


Model : WAK-S

Main Reagent: *N,N*-Diethyl-*p*-phenylenediamine Sulfate

Measuring Range: 0.1- 5 mg/L (ppm)

How to Use

Follow procedure ①-④ quickly. If taking long time after ①, will result in false negative reading.



- ① Fill the Cell (PACKTEST Square Cup) up to the line (1.5mL) with sample, and add 2 drops of K-1 Reagent (Bottle).
- ② Remove the colored line at the top of the tube to clear the aperture.
- ③ Press the tube's side wall to expel the air and hold the tube.
- ④ Immerse the aperture of the tube into the Cell, pressing it against the bottom, and release finger to take all the sample from the Cell into the tube. Invert the tube back and forth lightly for 5 to 6 times.
- ⑤ Compare the actual color in the tube with Standard Color after 3 min.

How to Read the Result

After the reaction time, compare the color of the tube with Standard Color. The nearest color indicates the concentration value of the analyte in your sample. A color between two standard colors indicate the value between them.

Handling of PACKTEST Before and After Use

K-1 Reagent and content of the tube is **Strong Acid**.

First Aid

Eye Contact → Immediately flush eyes with water for at least 15 minutes, followed by consult with Ophthalmologist, even without any symptom.

Skin/Cloth Contact → Immediately flush contacted area with water.

Ingestion → Immediately rinse mouth.

If swallowed the content or any symptom appears, seek medical advice immediately.

Please refer to SDS for further information.

Storage

Keep unused PACKTEST tubes in the provided preserving bag after opening the laminated package and use them as soon as possible. Depending on the storage condition, the reagent may deteriorate in several days especially under the hot and humid weather.

Disposal

For business use, please follow in the manner consistent with relevant laws and regulations. Otherwise, the tube can be disposed as combustible waste.

PACKTEST Sulfide (Hydrogen Sulfide)

Caution

1. This method only measures Sulfur as form of Hydrogen Sulfide (H_2S), Hydrogen Sulfide ion (HS^-), Sulfide (S^{2-}). Sulfate and Sulfite are not measured.
2. Multiply 1.06 to obtained result, you can convert the result to Hydrogen Sulfide (H_2S)
3. The optimum pH upon reaction will be around 1. If the pH of the sample exceeds 9, please neutralize with dilute sulfuric acid prior to measurement.
4. A sample with sulfide more than 20mg/L will fades the color as concentration becomes higher. If sample has very high concentration so you can smell hydrogen sulfide, please dilute the sample prior to measurement.
5. If there is not sulfide in the sample, it may turn light pink.
6. Keep the sample temperature between 15-40°C. If the sample temperature is low, it requires longer reaction time.
7. After adding K-1 reagent, do NOT mix the solution and draw into the PACKTEST tube immediately. If mixing or taking long time, color development turns weaker and gives false negative reading.
8. Ensure that the PACKTEST tube is filled up to half.
9. Partially undissolved reagent will not affect the measurement.
10. When comparing to the Standard Color, please be sure to read under the daylight. It may be difficult to determine the color under the direct sunlight, certain florescent lights, mercury lamp or LED.
11. You can put the line back into the aperture to seal. This will avoid possibility of spilling the content of the tube.

Interference

Standard Color is prepared based on the standard solution. If there are some coexisting substances that may cause interference, please compare the result with official method or standard addition method for verification. Below is the list of interference data for a color development when adding each of the single substances to the standard solution.

≤1000mg/L	will not affect	... B(III), Ba ²⁺ , Ca ²⁺ , Cl ⁻ , K ⁺ , Mg ²⁺ , Na ⁺ , NH ₄ ⁺ , Ni ²⁺ , PO ₄ ³⁻ , SO ₄ ²⁻ , Zn ²⁺ , Anionic Surfactant
≤500mg/L	"	... Al ³⁺ , F ⁻
≤200mg/L	"	... Cr ³⁺ , NO ₃ ⁻ , Phenol
≤100mg/L	"	... CN ⁻ , Fe ²⁺
≤50mg/L	"	... Fe ³⁺ , I ⁻ , Mo(VI)
≤20mg/L	"	... Cr(VI)
≤10mg/L	"	... Co ²⁺ , Mn ²⁺ , SO ₃ ²⁻
≤5mg/L	"	... NO ₂ ⁻ , S ₂ O ₃ ²⁻
≤2mg/L	"	... Cu ²⁺
Any Level	will affect	... Ag ⁺ , SCN ⁻ , Residual Chlorine

Seawater does not affect the result.

Oxidizing and Reducing substances may interfere the result.

When sulfide ions are mixed with metal ions, they become metal sulfides and may not be detected as sulfide ions.

【Caution】

- This product is made for analyzing water quality purpose only. Do not use for any other purpose.
 - This product contains small amount of chemicals. Please read instruction manual, GHS labels, SDS, and other necessary document thoroughly prior to use.
 - Please keep this information handy for future reference.
- <Safety>
- Please wash your hands thoroughly before and after the test. Do not inhale the chemical reagents.
 - It is highly recommended to wear protective gloves, eye protection, and mask upon using this product.
 - Avoid release chemical reagents or waste solution to the environment.
- <Storage>
- Please keep this product out of reach of children. Keep it in the dry and dark place at room temperature.
- <Other>
- Please check the expiration date shown on the box, and make sure to use within the date.
 - Specifications are subject to change without notice.



KYORITSU
CHEMICAL-CHECK Lab., Corp.

1-18-2 Hakusan, Midori-ku, Yokohama, Kanagawa
226-0006, JAPAN E-mail:eng@kyoritsu-lab.co.jp

2102